NINESTARS

Manual de Usuario

Nine Stars Worldwide Enterprise
1929 Mount Vernon Ave., Pomona, CA 91768
www.ninestarsusa.com

Introducción

Los basureros con sensor infrarrojo que detecta movimiento de Nine Stars son diseñados para que el manejo de desechos sea más limpio y fácil. Nuestros productos proveen una manera simple de desechar la basura en un ambiente libre de contacto. Simplemente colocar un objeto o la mano encima del sensor localizado estratégicamente (localizado en el labio de la tapa) y la tapa se abrirá automáticamente. Una vez que el objeto o la mano no están en el rango del sensor, la tapa se cerrara en segundos.
Nosotros en Nine Stars usamos los materiales de la más alta calidad y la ultima tecnología en nuestros productos para asegurar la durabilidad y función optima del producto. Gracias por su compra y esperamos sinceramente que disfrute este producto.

Vista General

Producto Patentado

Modelo: DZT-42-9BK y DZT-50-9BK
Nota: El basurero podria ser diferente a la foto demostrada. Sin embargo, las funciones son las mismas. Este modelo es para uso interno solaimente.

Instrucciones

Paso 1 Contenido de la caja

Quite todos componentes de basura pueden de la caja.
- Tapa
- Desechar contenedor
- Anillo de paquebote



Paso 2 Inserta baterías

Sitúe el compartimiento de batería debajo de la basura puede la tapa. Apriete la tapa de batería en con cuidado (ve esquema) y tira quitar la tapa de batería. Inserta tres (3) baterías PESADO de tamaño "C". Inserta las baterías de acuerdo con las astas positivas y negativas. Coloque la espalda de la tapa de batería sobre el compartimiento

Apriete la tapa de batería en y con cuidado asomsor arriba abrir. Para cerrar, para insertir el lado sin clip primero y apretar la tapa de batería. Asegurselo haca clic en asegurar que haya abrochado firmermente.

Paso 3 Inserta bolsa de basura

Inserta la bolsa de basura que utiliza el anillo de paquebote (ve esquema). Doble la bolsa de basura sobre las orillas del anillo de paquebote. Coloque la bolsa de basura y el anillo de paquebote en el contenedor de basura. Métase la bolsa completamente en la base del contenedor para que orillas de la bolsa no muestre una vez la tapa es el lugar encima de la base.

Inserta bolsa por el aro de anillo de paquebote primero, entonces dobla las orillas de bolsa sobre el anillo. **No puso paquebote anillo dentro de la bolsa**

Paso 4 Coloque la tapa en la base del cubo de la basura

Alinee la tapa con la base del cubo de la basura y coloque suavemente la tapa en la cima.

Coloque el lado trasero abajo primero

Paso 5 Gire la basura puede en/lejos

Sitúe el interruptor del poder en el debajo del lado de la tapa automática. Cuándo el interruptor está en el posiciono el cubo de la basura está "EN". Cuándo el interruptor está en la "O" posiciona la basura puede está apagado.



Paso 6 Cómo utilizar el cubo de la basura

Coloque la mano o un objeto dentro de pulgadas del sensor del movimiento (situó en la tapa). La tapa abrirá instantáneamente. Una vez que la mano o se opone está fuera del alcance del sensor la tapa cerrará dentro de segundos.

Características especiales

El manual abre y cierra botones

- El botón "abierto" situó en la tapa si apretado abrirá la tapa y tendrá lo abre hasta que el botón "cercano" sea empujado
- El botón "cercano" cerrará la tapa si la tapa ha sido abierta manualmente y también repondrá la tapa al modo del sensor.

Hechos técnicos

1. **Una luz roja destellará cuando la basura puede es prendido.**
2. **Una luz verde parecerá cuando la tapa abre.**
3. **Una luz roja parecerá cuando la tapa cierra.**
4. **Una luz amarilla del indicador parecerá cuando las baterías son bajo. Reemplace las baterias.**

⚠ Advertencia

1. No sumerja el cubo de la basura en el agua porque es equipado con muchos componentes eléctricos. El cubo de la basura puede ser enjugado con un trapo húmedo.
2. No fuerce manualmente la tapa cerca; esto puede causar el daño a los engranajes internos que permiten la tapa abra y para cerrar.
3. Reemplace baterías utilizadas en una manera oportuna para prevenir Fugas acidas de la batería. El ácido de la batería puede causar daños a los componentes eléctricos de la tapa de la basurero.
4. No coloque cubo de la basura en la luz directa del sol.
5. No mezcle nuevas baterías con baterías usadas.
6. No mezcle baterías alcalinas, con baterías estándar (carbón-zinc) ni recargable (ni-cad, ni-mh, etc.) baterías.

MOLESTE DISPARANDO

Errores	Soluciones
La tapa no abre	- Coloque el interruptor del poder en posiciona y verifica si baterias son colocadas en correctamente.
	- Enjugue el sensor con una tela seca.
	- Apriete el botón "cercano" para reponer el cubo de la basura.
La tapa no cierra	La luz del indicador es un constante verde - El cheque para ver si hay cualquier objeto dentro del área de sensor. Si hay, los quita.
	- Si algo bloqueó la tapa del fin, quita el articulo y aprieta el botón "cercano" para reponer su cubo de la basura.
La tapa abre lentamente y la luz de indicador destella Amarillo	La luz del indicador es amarilla - El poder de Batería es bajo. Reemplace las baterías.

La nota: Si el encima de soluciones no corrige el problema contacta por favor Nine Stars Worldwide Enterprise. Servicio de atención al cliente..

Garantía limitada

¿Qué cubre esta Garantía?
- Esta garantía cubre el mecanismo electrónico de la tapa como el chip, el motor, caja de engranaje y circuitos eléctricos.

¿Cuánto dura la garantía?
- Esta garantía es válida un año de la fecha de la compra.

¿Qué acciones tomara Nine Stars Worldwide Enterprise?
- Nine Stars reemplazara o reparara la tapa defectuosa.
- El cliente es responsable de devolver el la tapa defectuosa (la tapa entera) a Nine Stars Worldwide Enterprise. El cliente es También responsable de los cargos de envío de la tapa defectuosa a Nine Stars Worldwide Enterprise. Nine Stars Worldwide Enterprise pagara los cargos de envío de la tapa reemplazada al cliente si está cubierta bajo nuestro programa de garantía detallada en este documento.

¿Qué no cubre la garantía?
- La base de la unidad, las tapas de batería, aro interno (si es aplicable), recipiente Interior (si es aplicable), o ningún problema con la tapa automática causada por el Abuso, por el maltrato, o por los desastres naturales (como terremotos, las Inundaciones, y los fuegos) no son cubiertos.
- La Garantía es invalida si se cree que se intento reparar el producto por alguien fuera de Nine Stars Worldwide Enterprise resultando en danos de la tapa automática del basurero.

¿Cómo se consigue el servicio de garantía?
- Para tener derecho del servicio bajo esta garantía POR FAVOR devolver la tarjeta de garantía incluida en su basurero con una copia del comprobante de compra (como una copia del recibo original de ventas) dentro de 30 días de la compra.
- Si usted tiene alguna pregunta o problemas técnicas por favor siéntase libre de Llamar a nuestra oficina en:

1-909-620-8877, M-F, 9:00am to 5:30pm PST

¿Cómo aplica ley de estado?
- Esta garantía le da derechos legales especificos y usted también puede tener otros derechos que varían del estado a estado.

La tarjeta de la garantía es una forma separada. Envíe por favor la espalda completada de forma a Nine Stars Worldwide Enterprise.

Nine Stars Worldwide Enterprise
1929 Mount Vernon Ave., Pomona, CA 91768

NINESTARS

User's Manual

Nine Stars Worldwide Enterprise
1929 Mount Vernon Ave., Pomona, CA 91768
www.ninestarsusa.com

Introduction

Nine Stars infrared motion sensor trashcans are designed and created to make dealing with trash cleaner and easier. Our products provide an effortless way to dispose of trash by providing a touch –free environment. Simply put an object or hand above the strategically placed infrared motion sensor (located near the lip of the lid) and the lid will automatically open. Once the object or the hand is no longer within the sensor's range the lid will automatically close within seconds.
We at Nine Stars use the highest quality materials and the latest technology in our products to insure reliable function and durability. Thank you for your business and we sincerely hope that you enjoy your unit.

Overview



Patented Product

Model DZT-42-9BK and DZT-50-9BK
Note: Trash can may not be the same as the above photo. However, the functions are the same. This model is to be used in door.

Instructions

Step 1 Contents of the box

Remove all components of trash can from the box.
- o Lid
- o Trash container
- o Liner ring



Step 2 Insert batteries

Locate the battery compartment underneath the trash can lid. Squeeze the battery cap in carefully (see diagram) and pull to remove the battery cap. Insert three (3) HEAVY DUTY "C" size batteries. Insert the batteries in accordance with the positive and negative poles. Place the battery cap back over the compartment.

Squeeze battery cap in and carefully lift up to open. To close, insert side without clip first and push the battery cap down. Make sure it clicks to ensure that it's securely fastened.

Step 3 Insert trash bag

Insert the trash bag using the liner ring (see diagram). Fold the trash bag over the edges of the liner ring. Place the trash bag and the liner ring in the trash container. Tuck the bag completely into the base of the container so that edges of the bag do not show once the lid is placed on top of the base.

Insert bag through the liner ring hoop first, then fold bag edges over the ring.
DO NOT put liner ring inside the bag

Step 4 Place the lid on the base of the trash can

Align the lid with the base of the trash can and gently place the lid on top.

Place rear side down first

Step 5 Turn the trash can on/off

Locate the power switch on the underneath side of the automatic lid. When the switch is in the "I" position the trash can is "ON". When the switch is in the "O" position the trash can is "OFF".

Step 6 How to use your trash can

Place your hand or an object within inches of the motion sensor (located on the lid). The lid will open instantaneously. Once your hand or object is out of range of the sensor the lid will close within seconds.

Special Features

Manual open and close buttons

- The "open" button located on the lid if pressed will open the lid and hold it open until the "close" button is pushed.
- The "close" button will close the lid if the lid has been manually opened and will also reset the lid to sensor mode.

Technical Facts

1. A red light will flash when the trash can is in the "ON" position.
2. A green light will appear when the lid opens.
3. A red light will appear when the lid closes.
4. A yellow indicator light will appear when the batteries are low. Replace the batteries.

FCC Instructions

CAUTION:Users' modifications not approved by Nine Stars could void user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

⚠ Warning

1. Do not submerge the trash can into water because it is equipped with many electrical components. The trash can can be wiped with a damp cloth.
2. Do not manually force the lid close; this can cause damage to the internal gears that allow the lid to open and close.
3. Replace used batteries in a timely manner to prevent battery acid leakage. Battery acid may cause damage to the electrical components of the trash can.
4. Do not place trash can in direct sunlight.
5. Do not mix new and used batteries.
6. Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh,etc.) batteries.

TROUBLE SHOOTING

Errors	Solutions
Lid does not open	- Place the power switch in"I"position and check if batteries are placed in correctly.
	- Wipe the sensor with a dry cloth.
	- Press the "close"button to reset the trash can.
Lid does not close	Indicator light is a constant green - Check to see if there are any objects within the sensor area. If there are, remove them.
	- If something blocked the lid from closing, remove the item and press the "close" button to reset your trash can.
Lid opens slowly and Indicator light flashes yellow	Indicator light is yellow - Battery power is low. Replace the batteries.

Note: If the above solutions do not correct the problem please contact Nine Stars Worldwide Enterprise Customer Service.

Limited Warranty

What does this Warranty cover?
- This warranty covers the electronic mechanism of the lid such as the computer chip, motor, gear box and electrical circuits.

How long does the coverage last?
- This warranty is valid one year from the date of purchase.

What will Nine Stars Worldwide Enterprise do?
- Nine Stars will fix or replace any defective or malfunctioning lid.
- Customer is responsible for returning the defective of malfunotioning lid (entire top unit of the Trash Can) to Nine Stars Worldwide Enterprise. The customer is also responsible for shipping charges to return the product to us. Nine Stars Worldwide Enterprise will pay for shipping charges back to the customer if the lid is covered under our warranty program outlined in this document.

What does the warranty not cover?
- The base of the unit, battery caps, liner rings (if applicable), inner bucket (if applicable), or any problems with the automatic lid caused by abuse, misuse, or natural disasters (such as earthquakes, floods, and fires) are not covered.
- Warranty is voided if it is deemed repairs were attempted by anyone other than Nine Stars Worldwide Enterprise that resulted in damage to the automatic lid.

How do you get service?
- In order to be eligible for service under this warranty PLEASE return the warranty registration card attached with a proof of purchase (such as a copy of original sales receipt) within 30 days of purchase.
- If you have any technical questions or problems please feel free to call our office at:

1-909-620-8877, M-F, 9:00am to 5:30pm PST

How does state law apply?
- This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

The warranty card is a detached form. Please mail the completed form back to Nine Stars Worldwide Enterprise.

Nine Stars Worldwide Enterprise
1929 Mount Vernon Ave., Pomona, CA 91768

温红家居 本商品客户，请保存可能发证。 特别注意保存说明书，毕业后用不完全。